




www.ICOR.BE

NOTE: Gel pads have a delicate structure, be gentle in use in order to avoid deformation or rupture. The very-soft-sensor-gel-pad can be assembled many times, it doesn't stick, it can be dirty, washed and can be reinstalled.

FLEXIBLE SILICONE PAD FOR SENSOR - ROUND 27mm. ICOR REF.:



FLEXIBLE SILICONE PAD FOR SENSOR - ROUND 31MM - ICOR REF.: RSVS02



FLEXIBLE SILICONE PAD FOR SENSOR - ROUND 43MM W/ OVAL CUT OUT- ICOR REF.: RSVS04



FLEXIBLE SILICONE PAD FOR SENSOR - ROUND 43MM W/ ROUND CUT OUT - ICOR REF.: RSVS05



FLEXIBLE SILICONE PAD FOR SENSOR - RECTANGLE 37X46MM - ICOR REF.: RSVS06



FLEXIBLE SILICONE PAD FOR SENSOR - RECTANGLE 25X34MM - ICOR REF.: RSVS07



FLEXIBLE SILICONE PAD FOR SENSOR - ROUND 27MM W/ EXTENSION- ICOR REF.: RSVS08



FLEXIBLE SILICONE PAD FOR SENSOR - TRAPEZOID 31/45X41MM - ICOR REF.: RSVS09



FLEXIBLE SILICONE PAD FOR SENSOR - ROUND 43MM SCANIA (WITHOUT HOLE) ICOR REF.: RSVS10





www.ICOR.BE

NOTE: Gel pads have a delicate structure, be gentle in use in order to avoid deformation or rupture. The very-soft-sensor-gel-pad can be assembled many times, it doesn't stick, it can be dirty, washed and can be reinstalled.

SENSOR PAD TYPE 1. DIAMETER:
27MM. ICOR REF.: RSS01



SENSOR PAD TYPE 20/24. DIAMETER
31MM ICOR REF.: RSS02



SENSOR PAD TYPE 18/19. DIAMETER:
32MM. ICOR REF.: RSS03



SENSOR PAD TYPE H1. DIAMETER:
44MM. ICOR REF.: RSS04



SENSOR PAD TYPE H2. DIAMETER:
44MM. ICOR REF.: RSS05



SENSOR PAD TYPE 7. WIDTH: 37 MM
X LENGTH: 50 MM. ICOR REF.: RSS06



SENSOR PAD TYPE 6. WIDTH: 25 MM X
LENGTH: 34 MM. ICOR REF.: RSS07



SENSOR PAD TYPE 2-1. DIAMETER:
27MM. ICOR REF.: RSS08



SENSOR PAD TYPE 21. WIDTH: 41MM
X LENGTH: 45 MM. ICOR REF.: RSS09



SILICONE PAD FOR SENSOR - ROUND
44MM SCANIA (WITHOUT HOLE).
ICOR REF.: RSS10

